




USER INSTRUCTION MANUAL

NAME OF THE VARIOUS PARTS



IMPORTANT SAFEGUARDS

1. Read all instructions
2. Do not touch hot surfaces . Use handles or knobs.
3. To protect against electrical shock do not immerse Cord, plugs, or (state specific part or parts in question)
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any Manner . Return appliance to the nearest authorized service facility for examination , repair , or Adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors (this item may be omitted if the product is specifically intended for outdoor use).
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner , or in a heated oven.
11. Extreme caution must be used when moving an appliance hot oil or other hot liquids.
12. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off " , then remove plug from wall outlet.
13. Do not use appliance for other than intended use.
14. Avoid sudden temperature changes , such as adding refrigerated into a heated pot.

SAVE THESE INSTRUCTIONS

USAGES

1. First evenly spread the grass type of medicine into the pot bottom. Then place one cluster after another of the grain type of medicine.
2. Pour amount of water that was specified by the Chinese medicine doctors and cover the pot. (Note: The water must at least exceed the entire thermal conductor located on the bottom of the pot.)
3. Before boiling, soak the herbal medicine in water for around 30 minutes . Then switch on the power supply for boiling.
4. During the decoction, you do not need to stir. Upon completion, the medicinal cooker will automatically turn to the keep warm function.
5. Do not keep the warm function on for more than 2 hours. The medicine materials may absorb the soup and decrease the medical effect.
6. Unplug the power supply, and pour out the soup and materials immediately. Clean the medicinal cooker with water. (Or for an easy clean purpose, pour water into the pot and let it soak for about 10 minutes before washing.) Please use a wet cloth or a sponge for cleaning. Do not use a hard or rough material to clean the Stainless.
7. Wipe dry the inner part, and store it carefully.
8. You are able to use the medicine pot repeatedly.

REMARKS

After the completion of the decoction , Both light will switch automatically to the green light,the keep warm mode. If no soup or liquid comes out when pouring,please make self-exmination by the following steps:

1. Without putting into the medicine materials, add only the water until exceeding the thermal conductor.
2. Switch on the power supply for starting.
3. When the water level is below the thermal conductor,and the medicinal cooker will switch automatically from the red light to the green,the cooker is still functioning properly. Please repeat the above usage steps.

SUNPENTOWN

Your Guarantee

If this product is found to be faulty as a result of faulty materials or workmanship within one year from date of purchase, it will be repaired free of charge.

This guarantee is subject to the following terms:

- Sunpentown must be notified of the fault.
- Proof of purchase must be presented to Sunpentown's nominated representative.
- The warranty will be void if the product is modified, misused or repaired by an unauthorized person.
- The warranty after repair will not be extended beyond the original one-year period.
- All replacement parts will be new or reconditioned.
- Parts, which are replaced, become the property of Sunpentown.
- The warranty applies for the use of the product in the USA only.

What is NOT COVERED:

- Warranty does not include freight charges.
- Incidental or consequential damage caused by possible defects with this product.
- Damage to product caused by improper power supply voltage, accident, fire, floods or acts of nature.
- Failure of product resulting from unauthorized modifications to the product.
- Improper installation or failure to perform the necessary maintenance.

This GUARANTEE is in addition to your Statutory Rights

SUNPENTOWN INTERNATIONAL INC.

21415 Baker Parkway, City of Industry, CA 91789-5236
909-468-5288 Fax: 909-468-5279

service@sunpentown.com

www.sunpentown.com
